



INSTALLATION INSTRUCTIONS

- 1. Trim the opening in your ceiling to 600mm x 600mm using minimum 90mm x 45mm framing timber. Refer Figure 1. **Ensure opening is square.**
- 2. For ease of installation remove the lid from the ceiling hatch frame by removing the spring bar.
- 3. Turn all the fixing tabs to the vertical position and insert the ceiling hatch into the opening, giving consideration to which direction you would like the ceiling hatch to open.
- 4. Fit the hatch frame into the opening, ensuring the flange sits tight to the ceiling. Fix all tabs to the framing timber. See Figure 2.
- 5. Replace the lid and check the it closes securely on the spring catches. Adjust if necessary.

Model: CH600600 0800 288 427 | www.sellwood.co.nz